

BOX RANGE HOOD INSTALLATION INSTRUCTIONS:

- 1) Remove range hood from carton.
- 2) Remove detachable panel (*if applicable*) by grabbing top of panel and pulling forward. Be sure to hold the panel securely to prevent dropping and any resulting damage.
- 3) Lift upper hood section up and off hood base assembly and set aside.
- 4) Locate available studs in area where the Box Range Hood is to be installed.
- 5) Measure for desired height keeping in mind that exposed wood edges should be no less than 30" above cooking surface.
- 6) Secure range hood base to wall studs with at least four #8 x 2-1/2" framing screws.
- 7) Be sure that range hood is securely fastened to wall before attempting to install ventilation unit.
- 8) Install ventilation power pack into steel liner as outlined in ventilator instructions.
- 9) Mount liner/ventilator assembly to inside of hood base opening using available mounting holes and secure unit with wood screws (#8 x 5/8" not included).
- 10) Install ductwork or ductless kit according to ventilation manufacturer's guidelines.
- 11) Install upper hood section by lifting and placing on top of the mounted box range hood base.
- 12) Upper box hood section should nest with base assembly. Be sure that top section is aligned with base and flush with back wall.
- 13) Reinstall detachable panel (*if applicable*) by first seating panel bottom on top of mantel shelf, then aligning clips and applying pressure, first at bottom and then at the top, being careful to keep fastening clips aligned throughout.

